

Material Adicional da Aula sobre Sensores

Principais fatores de cortes das principais marcas

- 1.7 × - Sigma DP1, DP2 Sigma, Sigma SD15, SD14 Sigma, Sigma SD10, Sigma SD9.
- 1.62 × - Canon EOS 7D, 50D, 60D, 70D, 600D (T3i/X5), 650D (T4i/X6i), 700D (T5i/X7i), 1100D (T3/X50), 1200D (T5/X70), Canon EOS M.
- 1.57x - Nikon D3100, Nikon D3200
- 1.54 × - Pentax K-01, K-50, K-500, Samsung NX
- 1.53 × - Pentax K-3, Nikon D3300, Nikon D5300
- 1.52 × - Todos formato DX da Nikon câmeras DSLR, exceto D3100, D3200, D3300 e D5300; todos Fujji; Sony (exceto para o full-frame α 850, 7 e α α 7R); Sigma SD1, Sigma SD1 Merrill, Sigma DP1 Merrill, Sigma DP2 Merrill.
- 1.3 × ‡ - Canon EOS-1D Mark IV, 1D Mark III, 1D Mark II (e Mark II N), EOS-1D, Kodak DCS 460 †, DCS 560, DCS 660, DCS 760, Leica M8, M8.2